


How to configure an Xbox One Device to Open DNS



Open DNS

Open DNS provides a cloud-delivered network security services, delivering automated protection against advanced attacks for any device, no matter where it is. Family shield is pre-configured to block adult content, you can set it up and forget about it.

How to Configure

- 1. Go to the home screen.
- 2. Go to settings.
- 3. Click on network.
- 4. Find advanced settings.
- 5. Select **DNS Settings.**
- 6. Choose Manual.
- 7. Change current DNS server addresses to Open DNS addresses.
- 8. Save changes.

How to configure is settings not on homepage

- 1. Go to the home screen.
- 2. Select my games and apps.
- 3. Find settings.
- 4. Click on **network.**
- 5. Find advanced settings.
- 6. Select DNS Settings.
- 7. Choose Manual.
- 8. Change current DNS server addresses to Open DNS addresses.
- 9. Save changes.

Additional Information

Open DNS Server addresses:-Preferred: - 208.67.222.123, Alternate: - 208.67.220.123